Nintendo DS Download Station Instructions:

1. Press POWER on your Nintendo DS.

2. In the Nintendo DS MAIN MENU screen, select DS Download Play. If the Nintendo DS MAIN MENU screen does not appear, power down the Nintendo DS and remove any Nintendo DS or Game Boy Advance game cartridges.

3. Select the DS Download Station banner.

4. Press the A Button to confirm download of the DS Download Station software.

5. On the DS Download Station menu screen, use the stylus to select the content you would like to download. You may also use the control pad to scroll through the menu screen. Once the desired content is highlighted, press the A Button to download.

6. On the Download Confirmation Screen, select YES to download the content, or Cancel to return to the DS Download Station main menu system.

7. Once the content is successfully downloaded, it will remain in the Nintendo DS until the power is turned off.

*You can only have one download (game, movie, etc.) on your Nintendo DS at a time.
*If you are experiencing problems downloading, turn off your Nintendo DS and try again.
*The download process may pause before it completes; continue to wait until it is complete.
*To download successfully, you will need to be within 15 ft. of the designated location.

Problems downloading? Call 1-800-255-3700 for assistance.